



Reinigen: Die Verschlusskappe öffnen und den Trinkstutzen nach oben ziehen. Anschließend den Verschluss abdrehen und den Dichtring durch Klopfen auf eine feste Unterlage lösen. Alle Teile vor dem ersten Gebrauch gründlich mit warmen Wasser, einer weichen Spülbürste und etwas Spülmittel reinigen. Vor dem Zusammensetzen alle Teile mit klarem Wasser spülen und gut trocknen lassen. Nicht geeignet für heiße und kohlenensäurehaltigen Getränke!

Cleaning: Open the cap and pull up the drinking nozzle. Then untwist the screw top and remove the sealing ring by tapping it against a firm surface. Clean all parts thoroughly using warm water, a soft washing-up brush and a little washing-up liquid before the first and every subsequent use. Rinse and allow the parts to dry before reassembling them. Not suitable for hot or carbonated beverages.



Gebrauchsanweisung / Reinigung:

- Vor Erstinutzung Produkt in Einzelteile zerlegen, diese reinigen und für 5 Minuten in kochendes Wasser geben. Dies dient der Hygiene.
- Vor jedem weiteren Gebrauch sorgfältig reinigen zur Sicherstellung der Hygiene.
- Spülen Sie die Trinkflasche im oberen Korb Ihrer Spülmaschine oder von Hand.
- Wir empfehlen alle lösbaren Teile abzunehmen, mit weicher Flaschenbürste und Spülmittel zu reinigen und unter fließendem Wasser klarspülen.
- Alle Teile sollten an einem gut belüfteten Ort gelegt werden, um vollständig zu trocknen.
- Bitte keine Scheuermittel oder Metallschwämme zur Reinigung benutzen.
- Bitte bewahren Sie die Teile an einem trockenen Ort, geschützt vor Sonnenlicht auf.
- Nicht für die Mikrowelle geeignet.
- Hinweise und Herstellerkontaktdaten aufbewahren

Instruction for use / cleaning

- Before using the product for the first time, disassemble it into individual parts, clean them and place them in boiling water for 5 minutes. This is for hygiene purposes.
- Clean carefully before each subsequent use to ensure hygiene.
- Rinse the drinking bottle in the upper basket of your dishwasher or by hand.
- We recommend removing all detachable parts, cleaning with a soft bottle brush and detergent and rinsing under running water until clear.
- All parts should be placed in a well ventilated area to dry completely.
- Please do not use abrasive cleaners or metal sponges for cleaning.
- Please store the parts in a dry place away from sunlight.
- Not suitable for microwave oven.
- Keep notes and manufacturer contact information.

sigikid, H.Scharrer & Koch GmbH & Co.KG

Am Wolfsgarten 8

95511 Mistelbach

Telefon: +49 (0) 9201 700

Telefax: +49 (0) 9201 / 70-20

E-Mail: info@sigikid.de

<https://sigikid.de/>